



PARTS LIST

ITEM	REQD	DESCRIPTION
1	1	CASING 1 1/2 x 1 x 6, 150# RF SERRATED
		CASING 3 x 1 1/2 x 6, 150# RF SERRATED
2	1	IMPELLER (CLOSED)
		IMPELLER (CLOSED)
3	1	NUT, IMPELLER
5	1	BEARING HOUSING (STANDARD)
6	1	CONTAINMENT SHELL, METAL
7	1	OUTER MAGNET, 1"
		OUTER MAGNET, 1 1/2"
		OUTER MAGNET, 2"
8	1	EYE BOLT
9	1	NUT, EYE BOLT
10	1	MOUNTING BRACKET (STANDARD)
15	1	HUB, 254/256TC, 284/286TSC
16	1	INNER MAGNET 1"
		INNER MAGNET 1 1/2"
		INNER MAGNET 2"
17	1	SHAFT
18	1	IMPELLER KEY
19	1	INNER MAGNET KEY
20	1	1/2" NPT PLUG (DRAIN)
22	2	THRUST WASHER, STANDARD
23	2	BEARING, STATIONARY (STANDARD)
25	4	PIN, SLEEVE BEARING
30	2	BEARING, JOURNAL (STANDARD)
31	2	PIN, THRUST BEARING
32	2	TOLERANCE RING, SHAFT
33	2	TOLERANCE RING, BEARING HOUSING (OLD)
34	1	SPACER (BEARINGS)
49	8	5/16-24 x 3/4 SHCS (SHELL/BRG HOUSING)
55	8	#8-32 x 1/2 SHCS (HUB/OUTER MAG)
56	2	3/8-16 x 1 1/4 SHCS (BRACKET/BEARING HSG.)
	4	3/8-16 x 1 1/4 SHCS (BRACKET/ADAPTER PLT.)
57	1	5/16-24 x 3/8 SHSS (HUB/SHAFT)
58	2	1/4-28 x 1/4 SHSS (SPACER/SHAFT)
61	8	3/8-16 x 2 SHCS (CASING/BRACKET)
70	1	O-RING (2-166) (CASING)
71	1	O-RING (2-049) (CONTAINMENT SHELL)
91	1	MOTOR ADAPTER PLATE (THIN)
92	1	MOTOR ADAPTER PLATE (THICK)
96	4	1/2-13 x 1 3/4 SHCS (MOTOR/ ADAPTER PLT.)